KRAFTWERK®

FAVORITE TOOLS SINCE 1979

EN

Instruction Manual

Precision scale

601.200.001

- 0.03 - 200 g
- Readability 0.01 g
- 6 MODES g oz gn ct ozt dwt
- Accuracy ±0.03 g
- Auto calibration
- Backlit
- Auto off 180 sec.
- AAA incl. 2x
- KW 2 years warranty



Thank you for purchasing your Precision scale. Please read all operating instructions carefully before use. This electronic scale is a precision instrument. With normal care and proper treatment, it will provide years of reliable service.

· Never load the scale with more than the maximum capacity.

· Overloading will permanently damage it!

· Avoid any exposure to extreme heat or cold, your scale works better when operated at normal room temperature. Always allow the scale to acclimate to normal room temperature for at least one hour before use.

· Give your scale sufficient warm up time. Usually 30 to 60 seconds before calibration to give the internal componentsa chance to stabilize.

· Keep your scale in a clean environment. Dust, dirt,moisture, vibration, air currents and a close distance to other electronic equipment can all cause an adverse effect on the reliability and accuracy of your scale.

· Handle with care. Gently apply all items to be weighed onto tray top. Although this scale is designed to be quite durable, try to avoid rough treatment as this may permanently damage the internal sensor.

· Avoid shaking, dropping or otherwise shocking the scale. This is a precision instrument and must be handled with extreme care.

· Only operate the scale on a stable, vibration free surface.

* To achieve accurate results, please always objects with in the round range on the platform.

OPERATION

Place the scale on a horziontal flat surface.
1. Press "ON/OFF" key to turn on the scale.
2. Wait until the LCD display shows "0.0" or "0.00".
3. Put the object(s) on the center of weighing platform.
4. Press "MODE" key to switch between the units.

TARE FUNCTION

1. Turn on scale as described above.
2. Place the "tare item" on the platform.
3. Prsee "TARE" and wait until the LCD display shows "0.0" or "0.00".
4. Add the "net-weight-item".

CALIBRATION

1. Turn the scale on by pressing the ON/OFF key.
2. Wait for the display to show "0.00 g" or "0.000 g" then pressand hold the MODE key until the display shows "CAL", then release.

3. Press the MODE key again. The display will flash "CAL" followed by the required calibration weight.
4. Place the required calibration weight on the center of the platform. The display will show "PASS" then return to normal weighing mode.
   Calibration is complete!

Repeat this process if something was going wrong.
Please check the availability of weights at the store you bought your scale from.

TROUBLESHOOTING

The primary reasons for inaccuracy or malfunction are low batteries, incorrect calibration, overload or operating on anunstable surface. Please keep this in mind and maintain andoperate your scale properly. The scale is a precise instrument and must be handled with the utmost care and caution.

DISPLAY ELIMINATION OF ERRORS	
[88888] [LO], Nothing, Battery Symbol	Change the batteries
[OUT2]	Re-calibirate the scale as shown above
[EEEEE]	You are overloading the scale. Removethe excessive load immediately!
[LLLLL]	The delicate weighing load cells have been damaged by misusing the scale (i.e. it was shocked, drop)

PRODUCT SPECIFICATIONS

MODEL NO.	601.200.001
Capacity	0.03 - 200 g
Readability	0.01 g
Accuracy	±0.03 g
Weighing Unit	g, oz, dwt, gn, ct, ozt
Calibration	Auto calibration from keypad
Power	AAA batteries x2 (included)
Auto off	180 seconds off (default)
Platform Size (L x W)	70 × 60 mm
Scale Size (L x W x H)	140 x 82.5 x 22.5 mm
Net Weight	174 g



Waste electrical products should not be disposed of together with household waste. Please recycle where designated facilities exists. Check with your local authority or retailer for recycling advice.

- The battery must be removed from the appliance before it is scrapped.
- The appliance must be disconnected from the main power supply when removing the battery.
- The battery must be disposed of safely.

WARRANTY

We do not take responsibility for any damage caused by misuse or any use that is not in compliance with the safety standards described herein.

CUSTOMER SERVICES

Contact your local importer of your specialized dealer to obtain address of our service department.

FROM DATE OF PURCHASE RECEIPT
2 YEAR GUARANTEE
ON MATERIAL OR PRODUCTION DEFECTS

KRAFTWERK®

FAVORITE TOOLS SINCE 1979

KRAFTWERK Group AG
Mettlenbachstrasse 23
CH-8617 Mönchaltorf
Switzerland
Tel. +41-44 949 40 50

KRAFTWERK Sàrl.
25, rue du Stade
F – 67870 Bischoffsheim
France
Tel. +33-388 48 64 50

www.kraftwerktools.com