KRAFTWERK®

FAVORITE TOOLS SINCE 1979

EN

Instruction Manual

Line Laser Level SMART LINER

620.000.001




FEATURES


1. Power switch
2. Battery slot
3. 1/4" connection thread screw
4. Laser line output window
5. Lock button



OPERATION

Open the battery cover, insert 2 AA batteries and shut off the battery cover. Turn on the switch, the horizontal and vertical laser lines will be on. Press button,the horizontal and vertical lines will be off. Press button, you get laser lines on with lock, meaning the laser doesn't flash for self leveling warning, with which you have tilt laser line projected.





NOTICE

1. Unit is supposed to be put on a level surface, like desk or ground.Self-leveling range is ±4°, it will flash if the unit is out of self-leveling range.
2. Please switch off and put the unit into the soft bag to protect it when it's not in use. Laser class 2 m warning label on the laser instrument.The instrument is a laser class 2 m laser product with power < 1 mW and wavelength 635-670 nm. Laser is safe in ordinary conditions of usage.



SPECIFICATIONS

Self-leveling range	±4°
Precision	±3 mm / 10 m
SMART LINER Wave lengt	635-670 nm
Laser safety class	Class 2 m
Working range	20 m
Power/Adapter	2 x AA Batteries
SMART LINER Operating time	22 h
Operating temperature	-10°C~ 45°C
Size	70.5 x 47 x 66 mm
Net weight	0.15 kg

PACKING



SMART LINER



MINI Adjusting Stand

CLEANING RECOMMENDATIONS

It is cleaned using a damp cloth with soap and water. The plastic parts should never be cleaned with any solvent.

Neither strong detergents nor any harsh chemicals should be used to clean the tool. The device should not be dipped into the water directly.

Cleaning of the laser lens should be done using a soft cloth with a few drop of glass cleaner.

MAINTENANCE

Proper calibration of a Laser level is the crucial part of its maintenance. This determines the level of accuracy In any measurement. The laser levels should never be shaken, dropped or knocked down. To avoid risks of damages and dangers that can be caused by the device, it should be operated by a skilled person. Without the required expertise, this device should never be opened or dissembled.

WARRANTY TERMS CONDITIONS

The Laser level is covered by our 12 months warranty against defective workmanship or faulty parts commencing on the date that the product was purchased.

THE WARRANTY CEASES IF

The original serial number is removed or tampered with. The Product is repaired, serviced or interfered with in any way other than by an approved repairer. The Product is damaged by droppage, accident, misuse, failure to keep free of dust and water, incorrect operation, leaking batteries, incorrect battery voltage, usage outside specified temperature range or use for which the Product wasn't designed. The Product is rented out .

USAGE SCENARIOS





Waste electrical products should not be disposed of together with household waste. Please recycle where designated facilities exists. Check with your local authority or retailer for recycling advice.

- The battery must be removed from the appliance before it is scrapped.
- The appliance must be disconnected from the main power supply when removing the battery.
- The battery must be disposed of safely.

WARRANTY

We do not take responsibility for any damage caused by misuse or any use that is not in compliance with the safety standards described herein.

CUSTOMER SERVICES

Contact your local importer of your specialized dealer to obtain address of our service department.

FROM DATE OF PURCHASE RECEIPT
2 YEAR GUARANTEE
ON MATERIAL OR PRODUCTION DEFECTS

KRAFTWERK®

FAVORITE TOOLS SINCE 1979

KRAFTWERK GROUP AG
Mettlenbachstrasse 23
CH-8617 Mönchaltorf
Switzerland
Tel. +41-44 949 40 50

KRAFTWERK Sàrl.
25, rue du Stade
F – 67870 Bischoffsheim
France
Tel. +33-388 48 64 50

www.kraftwerktools.com