KRAFTWERK®

FAVORITE TOOLS SINCE 1979

EN

Instruction Manual
LED warn light

702.000.001

LED
9.6 W 16 LED
7500 mcd

- +
CR123
3 V
1300 mAh

h	
1 - Rotate	15 h
2 - Quad Flash	15 h
3 - Single Blink	100 h
4 - Alternating Blinks	15 h
5 - SOS Rescue (Morse Code)	24 h
6 - Steady on - high	8 h
7 - Steady on - low	10 h
8 - 2 LED Flashlight	15 h
9 - 4 LED Flashlight	10 h
10 - Off	

10 m
IP67

IK20 T

40 m

-36°C - 116°C




PLEASE READ THE INSTRUCTIONS BEFORE USE

IMPORTANT NOTE:
The ON/OFF switch is intentionally stiff so as not to switch on by mistake.
Use a car key to switch ON/OFF (see photo below)

OPERATION
Press the ON/OFF button to rotate through the following 9 light patterns:

LIGHT SEQUENCES	RUN TIME
#1 - Rotate	15 Hours
#2 - Quad Flash	15 Hours
#3 - Single Blink	100 Hours
#4 - Alternating Blinks	15 Hours
#5 - SOS Rescue (morse Code)	24 Hours
#6 - Steady on - High	8 Hours
#7 - Steady on - Low	10 Hours
#8 - 2 LED Flashlight	15 Hours
#9 - 4 LED Flashlight	10 Hours

USING THE CAR KEY TO TURN ON/OFF



ALTERNATE OPERATION:
To turn the Warning Light off without cycling through the 9 light patterns, press and hold the ON/OFF button for 2 seconds. Two LEDs will flash five times and then turn off. When ready to operate again, press the ON/OFF button and it will return to the last flash pattern that was selected before turning off.


RANGE OF USE
1. Safer and ecologically better for the environment than flame style emergency road flares. NO spark, open flame, fumes or toxic chemicals are produced when using the Warning Light.
2. Shock resistant construction makes the Warning Light very durable and can withstand the impact of roadside traffic. Can even be run over by a truck and still operate. Used by Fire, Police and other emergency services.
3. Lie flat or on it's edge depending on your reference. Place on the road, at construction sites, vehicle bumper or other surface and anywhere needing emergency signaling.
4. The LED Warning Light is waterproof so it may be used for marine applications and safety in wet environments, including submerged to a depth of 33 feet. Will float, unless secured.
5. Using the magnet on the Warning Light, attach to any magnetic metal surface. Place on a vehicle, fence or other metal surface.

NOTE: It is not recommended that you disassemble the Warning Light. If not reassembled correctly it may result in failure of the waterproof seal and damage the unit.

IMPORTANT SAFEGUARDS

- **Read all the instructions before operating**
- **Do not look directly at the lights; may cause injury to your eyes**
- **Do not use alcohol, flammable solutions, or other solvents on or near this unit.**
- **Only clean with warm water and a soft cloth**
- **Administer close supervision when using around children**
- **Waterproof only when used in accordance with manufacture's instructions**


PARTS IDENTIFICATION




TECHNICAL INFORMATION

Battery	Lithium Battery - CR123A 3V
Temperature Range	-32°F to 240°F (-36°C to 116°C)
Dot & Traffic Safety Compliance	1. US DOT (FMCSA) 49 §CFR 392.25 & 393.95 (g) (prohibits the carrying of any flame-producing flare on any Commercial Motor Vehicle (CMV) transporting explosives; any cargo of flammable liquid or flammable compressed gas as a motor fuel). 2. MUTCD Type A (flashing) and Type C (Solid on) 3. NFPA 1901 Standards for Traffic Safety; Section6.7.3 Miscellaneous Equipment
Weight	200 g
Dimensions	108 x 111 x 35 mm


HOW TO REPLACE THE BATTERY



USING A FLAT SCREW DRIVER, UNSCREW THE 2 ALUMINUM SCREWS AND REMOVE...




TURN OVER THE PUCK,... PLACE THE SCREWDRIVER UNDER ONE OF THE TABS AND LIFT...



TWIST GENTLY TO OPEN, BE CAREFUL NOT TO DAMAGE THE RUBBER SEALING RING... OR THIS MAY RESULT IN THE FAILURE OF THE WATERPROOF SEAL...




LIFT OFF THE TOP COVER,...




REMOVE THE BATTERY RETAINER FROM THE CIRCUIT BOARD,...



REMOVE OLD BATTERY FROM BETWEEN THE TERMINALS AND PROTECTIVE BLACK BAND,...



REPLACE OLD BATTERY, BLACK BAND AND BATTERY RETAINER ON IT'S LOCATING PINS,...



REPLACE THE LID, MAKE SURE THE 3 TABS ALIGN IN THE SLOTS AND THEN PLACE THE 2 SCREWS

PLEASE NOTE

THE ON OFF SWITCH IS INTENTIONALLY STIFF SO AS NOT TO SWITCH ON BY MISTAKE - USE A CAR KEY TO SWITCH ON/OFF

Waste electrical products should not be disposed of together with household waste. Please recycle where designated facilities exists. Check with your local authority or retailer for recycling advice.
- The battery must be removed from the appliance before it is scrapped.
- The appliance must be disconnected from the main power supply when removing the battery.
- The battery must be disposed of safely.

WARRANTY
We do not take responsibility for any damage caused by misuse or any use that is not in compliance with the safety standards described herein.

CUSTOMER SERVICES
Contact your local importer of your specialized dealer to obtain address of our service department.

FROM DATE OF PURCHASE RECEIPT
2 YEAR GUARANTEE
ON MATERIAL OR PRODUCTION DEFECTS

KRAFTWERK®

FAVORITE TOOLS SINCE 1979

KRAFTWERK Europe AG
Mettlenbachstrasse 23
CH-8617 Mönchaltorf
Switzerland
Tel. +41-44 949 40 50

KRAFTWERK Sàrl.
25, rue du Stade
F – 67870 Bischoffsheim
France
Tel. +33-388 48 64 50

www.kraftwerktools.com